

Ink cartridge compatibility

- Cartouches d'Encre - Tableau de compatibilité
- Lista zgodno. ci wk.adow atramentowych
- Kompatibilitätsliste für Tintenpatronen
- Compatibilidad de cartuchos de tinta
- Lista de Compatibilidades de tinteiros
- Compatibilitätsverzeichnis inktpatronen



Printer Model - Epson Stylus Photo

Epson Stylus Photo 950	T0331	T0332	T0333	T0334	T0335	T0336												
Epson Stylus Photo R200/R300/ RX500/RX600/R220/R320/R340/RX620	T0481	T0482	T0483	T0484	T0485	T0486												
Epson Stylus Photo R800/R1800		T0542	T0543	T0544			T0548		T0547	T0549	T0541	T0540						
Epson Stylus Photo 2100	T0341	T0342	T0343	T0344	T0345	T0346	T0347	T0348										
Epson Stylus Photo R2400		T0592	T0593	T0594	T0595	T0596	T0597	T0598	T0599			T0591						
Epson Stylus Photo RX420/425/RX240/245	T0551	T0552	T0553	T0554														
Epson Stylus Photo RX700	T5591	T5592	T5593	T5594	T5595	T5596												

Printer Model - Epson Stylus C/Stylus CX Series

Epson Stylus C64 Series/C66 Series/ C84 Series/C86 Series/ - CX3600/CX3650/CX6400/CX6600	T0441	T0452	T0453	T0454							T0431*	T0442*	T0443*	T0444*
Epson Stylus C70/C70+/C80	T0321	T0322	T0323	T0324										
Epson Stylus C82/CX5200/CX5400	T0321	T0422	T0423	T0424										
Epson Stylus C63/C65PE/CX3500	T0461	T0472	T0473	T0474										
Epson Stylus C67/C87/C87PE CX4700/CX4100/CX3700	T06314	T06324	T06334	T06344										
Epson Stylus D68/D88/D88PE/DX4800/ DX4850/DX4200/DX4250/DX3800/DX3850	T0611	T061	T0613	T0614										

*For C84/C86 series, CX6400, CX6600 only



Black



Colour

Printer Model - Epson Stylus Photo

Epson Stylus Photo 700/710/EX/EX2	S020093	S020110
Epson Stylus Photo 720/750	S020187	S020193
Epson Stylus Photo 790/870/875DC/890/895/915	T007	T008
Epson Stylus Photo 810/830 Series/925/935	T026	T027
Epson Stylus Photo 900	T007	T009
Epson Stylus Photo 1200	S020187	T001
Epson Stylus Photo 1270/1290	T007	T00909
Epson Stylus Photo 2000P	T015	T016

Printer Model - Epson Stylus C/Stylus CX Series

Epson Stylus C20UX/C40UX/C40SX/CX40+	T013	T014
Epson Stylus C42/C44/C46	T036	T037
Epson Stylus C43/C45	T038	T039
Epson Stylus C48	T066	T067
Epson Stylus C60	T028	T029
Epson Stylus C62/CX3200	T040	T041
Epson Stylus Color 1160	S020189	S020191



Black



Colour

Epson Stylus C/Stylus CX Series continued

Epson Stylus Color 400/600	S020093	S020089
Epson Stylus Color 440/460/640/ 660/670	S020187	S020191
Epson Stylus Color 480/480SXU/580	T013	T014
Epson Stylus Color 500	S020093	S020097
Epson Stylus Color 680/685	T017	T018
Epson Stylus Color 740/760/860 2000/2500	S020189	S020191
Epson Stylus Color 800/850	S020108	S020089
Epson Stylus Color 880	T019	T020
Epson Stylus Color 900/980	T003	T005
Epson Stylus Color 1520	S020108	S020089

Printer Model - Epson PictureMate

Epson PictureMate
Epson PictureMate 500



T5570

Epson PictureMate 100



T5730